

Dr. Larsen's Methodology

- 1. Identify buildups**
- 2. Select buildups**
- 3. Use log-log plot of best usable buildup to get an initial estimate of slope of pressure change and permeability**
- 4. Use semi-log plot to find best match of permeability to data from the best buildup**
- 5. Confirm permeability matches all other usable buildups**