



1 Contingency: Alternative LCM Pills - Brinker Technology Bridging Platelets

Well Status

- Well is under blowout conditions.
- The Top Kill plan is to pump a momentum kill with only mud followed by cement. No attempt will be made to bridge or seal the flow upwards in the BOP.
- If the momentum kill operation does not kill the well, then Bridging Platelets® may be pumped to bridge BOP flow and allow well kill/cementing operations to proceed.
- Frac balls are also a contingency bridging option. The frac ball procedure is a part of the Top Kill Procedure.