



LAMP FUNCTIONS

BOP STACK FUNCTIONS

DIVERTER SPARE 1
OPEN VENT CLOSE

DIVERTER SPARE 2
OPEN VENT CLOSE

DIVERTER SPARE 3
OPEN VENT CLOSE

EDS
EDS SELECTOR
NORMAL CASING

DIVERTER SPARE 4
OPEN VENT CLOSE

DIVERTER SPARE 5
OPEN VENT CLOSE

DIVERTER SPARE 6
OPEN VENT CLOSE

MUD BOOST VALVE
OPEN VENT CLOSE

POD SELECT
BLUE VENT YELLOW

EMERGENCY STOP
STOP FUNCTION

LAMP ACCUMULATORS CHARGE
CHARGE ISOLATE

LAMP ACCUMULATORS DUMP
DUMP ISOLATE

UPPER ANNUAL PREVENTER
OPEN VENT CLOSE

LAMP TEST

OUTER BLEED VALVE
OPEN VENT CLOSE

INNER BLEED VALVE
OPEN VENT CLOSE

LOWER ANNUAL PREVENTER
OPEN VENT CLOSE

LAMP ARTICULATED ARM
EXTEND VENT RETRACT

CHOKE/KILL ISOLATION VALVE
OPEN VENT CLOSE

LAMP CONNECTOR GASKET RELEASE
RELEASE VENT/HOLD SPARE

LAMP CONNECTOR SECONDARY
UNLATCH VENT

LAMP CONNECTOR PRIMARY
UNLATCH VENT LATCH

CHOKE/KILL CONNECTORS PRIMARY
UNLATCH VENT LATCH

CHOKE/KILL CONNECTORS SECONDARY
UNLATCH VENT

STACK ACCUMULATORS CHARGE
CHARGE ISOLATE

STACK ACCUMULATORS DUMP
DUMP ISOLATE

BLIND HIGH PRESSURE SHEAR CLOSE
DE-ENERGIZE CLOSE

BLIND/SHEAR RAM PREVENTER
OPEN VENT CLOSE

ST LOOKS
VENT LOCK

CASING HIGH PRESSURE SHEAR CLOSE
DE-ENERGIZE CLOSE

CASING SHEAR RAM (NO SEAL)
OPEN VENT CLOSE

UPPER INNER KILL VALVE
OPEN VENT CLOSE

UPPER OUTER KILL VALVE
OPEN VENT CLOSE

UPPER OUTER CHOKE VALVE
OPEN VENT CLOSE

UPPER INNER CHOKE VALVE
OPEN VENT CLOSE

UPPER PIPE RAM PREVENTER
OPEN VENT CLOSE

STACK ARTICULATED ARM
EXTEND VENT RETRACT

LOWER OUTER CHOKE VALVE
OPEN VENT CLOSE

LOWER INNER CHOKE VALVE
OPEN VENT CLOSE

MIDDLE PIPE RAM PREVENTER
OPEN VENT CLOSE

BOP STACK FUNCTIONS

LOWER PIPE RAM PREVENTER
OPEN VENT CLOSE

LOWER INNER KILL VALVE
OPEN VENT CLOSE

LOWER OUTER KILL VALVE
OPEN VENT CLOSE

WELLHEAD CONNECTOR GASKET RELEASE
RELEASE VENT/HOLD HOLD

WELLHEAD CONNECTOR SECONDARY
UNLATCH VENT

WELLHEAD CONNECTOR PRIMARY
UNLATCH VENT LATCH