

# Third Variable, $\Delta P$ , Pressure Drop

$$\Delta P = \text{Initial Reservoir Pressure} - \text{Final Reservoir Pressure}$$

