

OVERBOARD SELECTOR/PRESELECT

PORT BOTH STARBOARD

DIVERTER OVERBOARD/MUD/GAS SEPARATOR

OVERBOARD VERTICAL MCS

DIVERTER PACKER

OPEN VENT CLOSE

SHAKER/TRIP TANK SELECT

SHAKER TRIP TANK

STANDPIPE HOLE FILL VALVE

OPEN VENT CLOSE

DIVERTER LOCKDOWN DOGS

UNLOCK VENT LOCK

MTL604

HPU Flow: 18

MTL

SURFACE FLOWMETER TOTAL IN GALLONS

FLOW SURFACE RESET

TRIP TANK HOLE FILL VALVE

OPEN VENT CLOSE

TELESCOPIC JOINT LOCK

EXTEND VENT RETRACT

DIVERTER SECTION

1/1 UPPER PACKER AIR PRESSURE

ACTUATE VENT

MTL604

Rys Cond Fil

MTL

SURFACE FLOWMETER RIGID CONDUIT

FLOW RESET

TUBING HANGER PIN

EXTEND VENT RETRACT

1/1 LOWER PACKER HYDRAULIC PRESSURE

ACTUATE VENT

MTL604

Hot Line Flow: 115.9

MTL

SURFACE FLOWMETER HOT LINE

FLOW RESET

DIVERTER SPARE 9

OPEN VENT CLOSE

TELESCOPIC JOINT BEARING ACTUATE

ACTUATE VENT

AUTO SHAM

MANUAL

DIVERTER SPARE 1

OPEN VENT CLOSE

DIVERTER SPARE 2

OPEN VENT CLOSE

DIVERTER SPARE 3

OPEN VENT CLOSE

EDS

EDS SELECTOR

NORMAL CASING

ENABLE

DISABLE

DIVERTER SPARE 4

OPEN VENT CLOSE

DIVERTER SPARE 5

OPEN VENT CLOSE

DIVERTER SPARE 6

OPEN VENT CLOSE

LMP FUNCTIONS

MUD BOOST VALVE

OPEN VENT CLOSE

POG SELECT

BLUE VENT YELLOW

ENABLE PUMP/VALVE

TO OPERATE FUNCTION

LMP ACCUMULATORS CHARGE

CHARGE ISOLATE

LMP ACCUMULATORS DUMP

DUMP ISOLATE

UPPER ANNULAR PREVENTER

OPEN VENT CLOSE

LMP TEST

OUTER BLEED VALVE

OPEN VENT CLOSE

INNER BLEED VALVE

OPEN VENT CLOSE

LOWER ANNULAR PREVENTER

OPEN VENT CLOSE

LMP ARTICULATED ARM

EXTEND VENT RETRACT

CHOKE/NULL ISOLATION VALVE

OPEN VENT CLOSE

LMP CONNECTOR GASKET RELEASE

RELEASE VENT/HOLD SPARE

LMP CONNECTOR REDUNDANT

LMP CONNECTOR PRIMARY

CHOKE/NULL CONNECTORS PRIMARY

UNLATCH VENT LATCH

CHOKE/NULL CONNECTORS SECONDARY

UNLATCH VENT