

Sandface Pressures (detailed scale from start of well turn-down)  
 Data for  $Q_0 = 60$  mbd,  $Cr = 12$   $\mu$ sips, Aquifer = 3.8x

Time	WIG Case, no. Zflow	Well ID	Sandface	WHP (PSI)	Time
08:00	00000	00000	0000	0000	08:00
08:00	00000	00000	0000	0000	08:00

**Sandface Pressures (detailed scale from start of well turn-down)**  
**Data for  $Q_0 = 60$  mbd,  $Cr = 12$   $\mu$ sips, Aquifer = 3.8x**

08:00	00000	00000	0	10000	08:00
08:10	00000	00000	0	10010	08:10
08:20	00000	00000	0	10020	08:20
08:30	00000	00000	0	10030	08:30
08:40	00000	00000	0	10040	08:40
08:50	00000	00000	0	10050	08:50
08:00	00000	00000	0	10060	08:00
08:10	00000	00000	0	10070	08:10
08:20	00000	00000	0	10080	08:20
08:30	00000	00000	0	10090	08:30
08:40	00000	00000	0	10100	08:40
08:50	00000	00000	0	10110	08:50
09:00	00000	00000	0	10120	09:00
09:10	00000	00000	0	10130	09:10
09:20	00000	00000	0	10140	09:20
09:30	00000	00000	0	10150	09:30
09:40	00000	00000	0	10160	09:40
09:50	00000	00000	0	10170	09:50

CONFIDENTIAL

BP-HZN-2179MDL07117807  
 BP0509-097912

TREX 009320.0017

TREX-009320.0017